EK-50 Update to Ver 2

Changes in Ver 2 from Ver 1.4

- A "UserStyleLoad" menu has been added to the MEDIA functions.
  You can now load and use Pa50, Pa50SD and microARRANGER user styles on the EK-50.
- You can now save variation and intro settings when saving your style to a set list.

What you will need

- USB Memory stick supported by EK-50
- Computer with USB port
- AC adapter KA390 or eight AA batteries

Make sure the batteries are brand new if using alkaline or fully charged if using NiMH batteries.

Updating the software

1. Prepare a USB memory stick that has been formatted by EK-50.
2. Insert the USB memory stick into your computer.
3. Extract EK-50_xxxx.zip.
4. Copy "UPDATE.BIN" on the root of the USB memory stick.
5. Insert the USB memory stick containing the new system file into your EK-50, and turn on the power.
6. Push MEDIA button
7. Select "[SystemUpdate]" from the Media menu.

8. Press Media button. Select “Yes [MEDIA]” by encoder and press Media button again. New version will appear. Press Media button.

Do not update to version older than ver2.1.

9. A confirmation message will appear. Select “Yes [MEDIA]” by encoder. Press Media button to begin the update operation.

Do not turn off EK-50 while update is in progress.

10. EK-50 will display the following screen when update is complete.

11. Long push the power button. EK-50 will now turn off. The system has been updated.